Digital Camera Module

取扱説明書

Operating Instructions

お買い上げいただきありがとうございます。

電気製品は、安全のための注意事項を守らないと、火災や人身

この取扱説明書には、事故を防ぐための重要な注意事項と製品の取り扱いか たを示してあります。この取扱説明書をよくお読みのうえ、製品を安全にお 使いください。お読みになったあとは、いつでも見られるところに必ず保管 してください。

XCD-V60CR/SX90CR/U100CR (Color model)

XCD-V60/SX90/U100 (Black and white model)

© 2007 Sony Corporation Printed in Japan



安全のために

ソニー製品は安全に充分に配慮して設計されています。しかし、電気製品は まちがった使いかたをすると、火災や感電などにより死亡や大けがなど人身 事故につながることがあり、危険です。事故を防ぐために次のことを必ずお 守りください。

- 安全のための注意事項を守る。
- **故障したり破損したら使わずに、ソニーのサービス窓口に相談する。**

警告表示の意味

この取扱説明書および製品では、次のよ うな表示をしています。表示の内容をよ く理解してから本文をお読みください。


この表示の注意事項を守らないと、火災

や**感電**などにより**死亡や大けが**など 人身事故につながることがあります。

/| 注意 この表示の注意事項を守らないと、火災

やその他の事故によりけがをしたり周 辺の物品に**損害**を与えたりすることが あります。

注意を促す記号



分解禁止

行為を指示する記号



下記の注意を守らないと、**火災**や**感電 落下**により**死亡ゃ大けが**につながること があります。

設置は確実に



設置については、必ずお買い上げ店または、巻末に記載 設置は、本機と取り付け金具を含む重量に充分耐えられ る強度があることをお確かめのうえ確実に取り付けて ください。充分な強度がないと、落下して、大けがの原 因となります。

また、1年に一度は、取り付けがゆるんでいないことを 点検してください。

レンズは確実に取り付ける



レンズはネジ部をしっかり締めて取り付けてください。 取り付けかたがゆるいと、レンズがはずれてけがの原因 となることがあります。

また、1年に一度は取り付けがゆるんでいないことを点 検してください。

/ 注意

下記の注意事項を守らないと、**けが**をしたり周辺の物品に**損害** を与えることがあります。

内部に水や異物を入れない



水や異物が入ると、火災の原因となります。 万一、水や異物が入ったときは、すぐに本機が接続され ている電源供給機器の電源を切り、DC電源ケーブルや 接続ケーブルを抜いて、ソニーのサービス窓口にご相談

分解しない、改造しない



分解や改造をすると、火災やけがの原因となります。 点検および修理は、ソニーのサービス窓口にご依頼くだ さい。

カメラケーブルを傷つけない



禁止

カメラケーブルを傷つけると、火災や故障の原因となる ことがあります。次の項目をお守りください。

- 設置時に、製品と壁やラック、棚などの間に、はさみ込 まない。
- ●カメラケーブルを加工したり、傷つけたりしない。 重いものをのせたり、引っ張ったりしない。
- 熱器具に近づけたり、加熱したりしない。
- ◆カメラケーブルを抜くときは、必ずプラグを持って抜

芯線の露出や断線などでカメラケーブルが傷んだら、お 買い上げ店に交換をご依頼ください。そのまま使用す ると、火災の原因となります。

指定された専用機器に接続する



指定された以外の機器を接続すると、火災や故障の原因 となることがあります。

指定された接続ケーブルを使う



この取扱説明書に記されている接続ケーブルを使わな

Owner's Record

The model and serial numbers are located on the bottom. Record the serial number in the space provided below. Refer to these numbers whenever you call upon your Sony dealer regarding this product.

Model No. _____ Serial No. ____

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

IMPORTANT

The nameplate is located on the bottom.

Power Supply

The unit must always be operated with a 12V DC class 2 power supply. In the USA, use a power supply which is UL Listed.

For the customers in the U.S.A.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this

All interface cables used to connect peripherals must be shielded in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules.

For customers in Europe

This camera is not intended for use in security applications in the meaning of the European standard series EN 50132 (Alarm systems -CCTV surveillance systems for use in security applications).


For the customers in Europe


The manufacturer of this product is Sony Corporation, 1-7-1 Konan, Minato-ku, Tokyo, Japan.


The Authorized Representative for EMC and product safety is Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters please refer to the addresses given in separate service or guarantee documents.

This apparatus shall not be used in the residential area.

Α A –1 カメラ/Camera 1 [™] GND1 0







カメラ設置の際は、周辺機器を含めてカメラに接続されている各機器間で接 地電位の差が生じないようにしてください。接地電位差により故障の原因 となる場合があります。設置の都合により電位差を生ずる場合は、機器の内

① IEEE1394b端子

電源について

- ② 12ピンI/Oコネクター端子
- ホスト機器(PCなど)
- 3 接地電位差

使用上のご注意

DC-700をご使用ください。

次のような場所での使用および保管はお避けください。

- 激しい振動や衝撃のある所。
- ●強力な電波を発生するテレビ、ラジオの送信所の近く。

お手入れ

レンズや光学フィルターの表面に付着したごみやほこりは、ブロアーで払っ てください。外装の汚れは、乾いた柔らかい布でふきとります。ひどい汚れ は、中性洗剤溶液を少し含ませた布でふきとった後、からぶきします。アル コール、ベンジンなどは、変質したり塗料がはげることがありますので、使用 しないでください。

モジュール、XCD-V60/SX90/U100は白黒デジタルカメラモジュールです。

転送速度800Mbpsのデジタル出力が可能。IEEE1394b端子を2つ搭載する ことにより、デイジーチェーン接続が可能です。

プログレッシブスキャンCCDの採用により、高精細で高速な画像が得られ

像出力が可能です。XCD-SX90CR/SX90は、SXGA対応の125万画素CCD により毎秒30フレームの画像出力が可能です。XCD-U100CR/U100は、 UXGA対応の200万画素CCDにより毎秒15フレームの画像出力が可能です。 また、正方画素CCDの採用により、画像処理時にアスペクト比の変換を行う 必要がありません。

外部トリガー機能

外部トリガー信号に同期させて任意のタイミングでシャッターを作動させ ることができます。

ことができます。

12ピンI/Oコネクター端子

IEEE1394b端子からの電源供給が不足する場合、12ピンコネクターから電 源を供給することができます。12ピンコネクターは、トリガー入力、ストロ ボ出力のほか、汎用のI/Oにも対応しています。

低消費電力 XCD-V60CR/V60/SX90CR/SX90では消費電力を2.8W(DC 12V入力時)、

筐体固定

XCD-U100CR/U100では3.0W (DC 12V入力時)に抑えました。

どめることができます。

撮影画面に出る下記の現象は、CCD撮像素子(Charge Coupled Device) 特有の現象で、故障ではありません。

白点


CCD撮像素子は非常に精密な技術で作られていますが、宇宙線などの影響 により、まれに画面上に微小な白点が発生する場合があります。 これはCCD撮像素子の原理に起因するもので故障ではありません。

また、下記の場合、白点が見えやすくなります。 ●高温の環境で使用するとき

- ゲイン (感度) を上げたとき
- スローシャッターのとき

スミア現象

れが発生することがあります。



折り返しひずみ

細かい模様、線などを撮影すると、ぎざぎざやちらつきが見えることがあり ます。

カメラモジュールを中心とした描画システムの構成品目は、次のとおりで す。基本構成には ● ~ ●、オプションの構成には ● ~ ●を使います。(カ メラモジュール以外はいずれも別売です。)

カメラモジュール

CCDを用いた、小型、高解像度のカメラです。

カメラモジュール裏面のIEEE1394b端子に接続し、電力の供給や映像信号の 送出、制御信号の授受を行います。接続不良やカメラ、ケーブルの破損を防 ぐため、固定ねじ付きのケーブルをお使いください。

カメラや用途に合ったレンズをお使いください。

△ カメラ用画像入力ボード(市販)

お使いのシステムに適したIEEE1394対応のボードをご使用ください。

転送速度800Mbpsで使用される場合は、IEEE1394b対応のボードをご使用 ⑤ 三脚アダプター VCT-ST70I (ソニー製)

ジュールの底部に取り付けます。 ⑥ カメラアダプター DC-700 (ソニー製)

AC電源から電力を供給する場合に、カメラモジュールに接続して使用しま

カメラケーブルCCXC-12P02N (2 m) /05N (5 m) /10N (10 m)

カメラモジュール裏面の12ピンI/Oコネクター端子に接続し、電力の供給や トリガー信号の授受を行います。

各部の名称と働き

図C 前面/上面/底面

③ カメラ固定用基準穴(底面)

Cマウント式のレンズとして、レンズマウント面からの飛び出し量が10mm 以下のものを使用してください。

② カメラ固定用補助穴(上面)

3の4つのネジ穴は、三脚アダプター取り付け用ネジ穴としても使用でき

When Installing the Camera

When you install the camera with various peripheral devices and if the devices have different ground electric potential, ground only one device. In case there is an ground electric potential difference, the camera may be damaged.

A-1 Basic configuration / A-2 Optional configuration

(2) 12-pin I/O connector

2 Abnormal electricity 3 Ground electric potencial difference 4 Power supply unit (DC-700/700CE)

Notes on Operation

Power supply

(1) IEEE1394b connector

1 Host device (e.g., PC)

Power is supplied to the camera module via the IEEE1394b cable connected to a PC. If the power supply is insufficient, use the DC-700/700CE that supplies stable

Foreign bodies Be careful not to spill liquids, or drop any flammable or metal objects in the

Locations for operation and storage Avoid operation or storage in the following places.

• Extremely hot or cold locations. Recommended temperature range is 0°C to 40°C (32°F to 104°F)

• Locations subject to strong vibration or shock

• Near generators of strong electromagnetic radiation such as TV or radio

Care Use a blower to remove dust from the surface of the lens or optical filter. Clean

the exterior with a soft, dry cloth.

with a dry cloth. Do not apply organic solvents such as alcohol which may damage the finish.

RGB Raw Data. The XCD-V60/SX90/U100 is a monochrome digital camera module.

800 Mbps. Two IEEE1394b connectors allow you to make up a daisy chain High resolution

The XCD-V60CR/V60 has a CCD of 330,000 pixels (VGA) and outputs a digital image at 90 frames per second. The XCD-SX90CR/SX90 has a CCD of 1,250,000 pixels (SXGA) and outputs at 30 frames per second. The XCD-U100CR/U100 has a CCD of 2,000,000 pixels (UXGA) and outputs at 15 frames per second. Because the CCDs are square pixel CCDs, you don't need to convert the aspect ratio in your image processing.

External trigger function

Electronic shutter

12-pin I/O connector

external trigger signals.

When power from the IEEE1394b connector is insufficient, power is supplied through the 12-pin connector. The 12-pin connector is also used for a trigger input and strobe output, and as a general-purpose I/O port.

SX90 or 3.0 W for the XCD-U100CR/U100, with 12 V DC input.

Body fixing

The mounting screw holes are provided in the reference plane on the lower surface of the body, allowing mounting with the absolute minimum deviation

Phenomena Specific to CCD Image Sensors


technologies, fine white flecks may be generated on the screen in rare cases, caused by cosmic rays, etc.

This is related to the principle of CCD image sensors and is not a malfunction.

• when operating at a high environmental temperature • when you have raised the gain (sensitivity)

• when using the slow shutter

Vertical smear When an extremely bright object, such as a strong spotlight or flashlight, is being shot, vertical tails may be produced on the screen, or the image may be



Aliasing

When fine patterns, stripes, or lines are shot, they may appear jagged or flicker.

System Components

optional configuration. (All the products except the camera module are

available separately.)

♠ Camera module

cable. To prevent a poor connection or damage to the camera or cable, use the cable equipped with fixing screws. C-mount lens (commercially available)

Use an appropriate lens for the camera module and usage. 4 Camera module interface board (commercially available)

6 VCT-ST70I tripod adaptor (Sony)

Attach this adaptor to the bottom of the camera module to fix the camera module to a tripod. **6** DC-700/700CE camera adaptor (Sony) Connect this adaptor to the camera module to enable power supply from an

25N (25 m, 82 ft) camera cable (Sony) Connect this cable to the 12-pin I/O connector on the rear panel of the camera

module. The cable is used for power supply and exchange of trigger signals.

1 Lens mount (C-mount)

Attach any C-mount lens or other optical equipment.

1 Lens mount face (2) 10 mm (13/32 inch) or less

Reference holes (bottom)

These precision screw holes are for locking the camera module. Locking the camera module into these holes secures the optical axis alignment.

The lens must not project more than 10 mm (13/32 inch) from the lens mount.

too. Screw the VCT-ST70I tripod adaptor into the four screw holes when you use

(continued on the reverse side)

指示

いと、火災や故障の原因となることがあります。



いずれかひとつの機器だけを接地するようにしてください。

A-1 基本構成/**A-2** オプションの構成

2 異常電流 4 電源(DC-700)

本機の電源は、PCからIEEE1394bケーブルを介して供給されます。電源供 給が不足する場合には、リップルやノイズの少ない安定した電源を供給する

使用・保管場所

●極端に暑い所や寒い所。適正使用温度は0~40℃です。

XCD-V60CR/SX90CR/U100CRはRAWデータ出力のカラーデジタルカメラ

IEEE1394b端子

高画質

XCD-V60CR/V60は、VGA対応の33万画素CCDにより毎秒90フレームの画

電子シャッター 露光時間は豊富な設定値の中から選択可能。最適な条件で画像を取り込む

筐体固定用のネジ穴がCCD基準面の含まれているフロントパネルの下部に あります。ここでカメラモジュールを固定すれば、光軸のずれを最小限にと

CCD特有の現象

強いスポット光やフラッシュ光などを撮影したときに、画面上に縦線や画乱

② IEEE1394bカメラケーブル(市販)

ホスト機器(PCなど)のPCIバススロットに挿入します。

三脚を使ってカメラモジュールを固定するとき、このアダプターをカメラモ

/25N (25 m)(ソニー製)

① レンズマウント部② 10mm以下

モジュールを固定すると、光軸のずれを最小限にとどめることができます。 ◆ 詳細はユーザーズガイドをご覧ください。

(裏面へ続く)

If the camera is very grimy, apply a cloth soaked in a mild detergent then wipe

Overview The XCD-V60CR/SX90CR/U100CR is a color digital camera module that outputs

IEEE1394b connector The camera module can output a digital image with a transfer speed of

and high-speed image output.

The camera module uses a progressive scan CCD and produces high-resolution

You can operate the shutter at any timing by synchronizing the shutter with the

You can select the exposure time from a variety of settings. This allows you to capture an image under optimal conditions.

Low power consumption The power consumption is decreased to 2.8 W for the XCD-V60CR/V60/SX90CR/

The following phenomena that may appear in images are specific to CCD (Charge

Although the CCD image sensors are produced with high-precision

Coupled Device) image sensors. They do not indicate malfunctions.

The white flecks especially tend to be seen in the following cases:

The camera module imaging system comprises the following products. Products 1 to 4 are used for the basic configuration, and 1 to 7 for the

This is a small-size, high-resolution, camera module using a CCD image sensor. 2 IEEE1394b camera cable (commercially available) Connect this cable to the IEEE1394b connector on the rear panel of the camera module. The power and image/control signals are transmitted through this

Install the board in a PCI bus slot of a host device such as a PC. Select an IEEE1394 interface board to match your system. Select an IEEE1394b interface board if you use the transfer speed of 800 Mbps.

ordinary AC power source. CCXC-12P02N (2 m, 6.6 ft)/05N (5 m, 16.4 ft)/10N (10 m, 32.8 ft)/

Location and Function of Parts and Operation Fig. C Front/Top/Bottom


2 Auxiliary holes (top)


For details, refer to the Technical Manual. Four screw reference holes 3 can be used as the tripod adapor screw holes,

Cマウント式のレンズや光学機器を取り付けます。 ご注意


カメラモジュール固定用に高い精度で切られたネジ穴です。ここでカメラ


ます。三脚を使うときは、この4つのネジ穴を使って三脚アダプター VCT-ST70lを取り付けます。






Ξ







▲ IEEE1394b端子

市販のIEEE130/bカメラケーブルを接続します

D級VJEEET394DJA フケーフルを接続しより。			
ピン番号	信号	ピン番号	信号
1	TPB-	6	VG
2	TPB+	7	NC
3	TPA-	8	VP
4	TPA+	9	TPBG
5	TPAG		

⑤ 12ピンI/Oコネクター端子

IEEE1394b端子からの電源供給が不足する場合、この端子から電源を供給す ることができます。

カメラケーブルCCXC-12P05Nなどが接続できます。

ピン番号	信号	ピン番号	信号
1	電源 (アース)	7	GPIO入力2
2	電源入力	8	GPIO出力2-
3	ISO(アース)	9	GPIO出力2+
4	ストロボ出力	10	GPIO入力1
5	GPIO出力1-	11	トリガー入力
6	GPIO出力1+	12	ISO(アース)

レンズの取り付け

1 レンズマウントキャップをはずす。

ご注意


2 レンズ(別売)を回して取り付ける。

光学フィルターの表面に付着したごみやほこりは、市販のブロアーで払って ください。

三脚の取り付け	EX

三脚アダプター VCT-ST70I (別売)をカメラモジュールに取り付けてから三 脚に取り付けます。 三脚の取付部のネジは取付面からの飛び出し量(ℓ)が下記のものを使用して ください。

ISO規格 ℓ: 4.5mm ~ 5.0mm ASA規格 ℓ: 0.197インチ ネジはハンドトライバーで締めつけてください。



ご注意

三脚アダプター (別売)を取り付けるときは、三脚アダプターに付属のネジ を使用してください。

カメラケーブルの接続

市販のIEEE1394bカメラケーブルでIEEE1394b端子とパソコンの1394bイ ンターフェース端子を接続してください。接続する際は、ケーブルのコネク ター部を持ち、固定するまでしっかりと差し込んでください。 その後、両側にある固定ねじを締め付けてください。

❶ IEEE1394b端子 2 固定ねじ

3 IEEE1394bカメラケーブル(市販)

ご注意

固定ねじがゆるむと、接続不良やカメラ、ケーブルの破損の原因となります。 固定ねじはしっかり締め付けてください。

IEEE1394b端子からの電源供給が不足する場合、カメラアダプター DC-

700(別売)とカメラケーブルCCXC-12P05N (別売)などを介して電源を供

12ピンI/○コネクター端子

給することもできます。

② カメラケーブル(CCXC-12P05Nなど)

4 CAMERA端子

⑤ ~ AC IN端子 6 トリガー発生器

|パーソナルコンピューターによるコントロール

本機はパーソナルコンピューターによりコントロールします。コントロー ルできる機能は以下の表のとおりです。

全モデル共通機能

制御項目	内容			
ゲイン	カラーモデル 0~+18 dB			
	白黒モデル	0 ∼ +24 dB		
シャッター	1/100,000~16秒1	1/100,000 ~ 16秒に可変		
ブライトネス	ペデスタルレベル	レの可変		
ガンマ		テーブル(10ビット)により、ガン 役定が可能(IIDC拡張機能)		
トリガー	Mode0(レジスクをサポート	ソフトウェアトリガーはブロードキャストコマン		
ストロボ出力	レジスターにより 号幅を制御	つ、露光開始からのディレイと信		
オートエクスポージャー	1	映像のレベルを検波して、ゲイン、シャッターに フィードバックをかけることにより、映像の平均 レベルを一定化		
オートエクスポージャー 検波枠設定	オートエクスポージャーの検波エリアの設定			
GPIO	12ピンコネクター	ーに割り当てるGPIOの制御		
メモリーショット	内蔵フレームメモリーに映像を保存し、あとで映像の読み出しを行う			
ISO Enable(ビデオス タート)	連続モードで画	像を転送開始		
OneShot/MultiShot	OneShot	画像1枚を転送		
	MultiShot	指定した枚数の画像を転送		
DataDepth	16ビットモード	寺に有効なビット長を示す		
Cameralnitialize	フィーチャーを初	刃期値にリセット		
メモリーチャンネル	PresetMemory0(工場出荷状態)および ユーザー設定チャンネル1 ch/15 ch切り換え可能			
1394バス同期	1394バスのサイクルタイムレジスターに同期して 露光のタイミングを決定			
トリガーディレイ	トリガー受信時、指定した時間後にトリガーを有効にする			
パーシャルスキャン	32ライン x 24ピクセルのユニットに分割可能			
ユーザーフリーメモリー	256バイトのユーザー使用可能なメモリーを装備			
バルクモード	メモリーチャンネ ら、連続して画像	マルを使用して設定を変えなが を取得		

XCD-V60CR/SX90CR/U100CR(カラーモデル)のみ

制御項目	内容
ホワイトバランス(Raw モード)	R、Bレベルの調整 オートホワイトバランス/ワンプッシュホワイトバランス
Gゲイン	Gゲインの調整
オプティカルフィルター	ベイヤーパターンの切り換え

XCD-V60/SX90/U100(白里モデル)のみ

ACD-V00/3A90/0100(日無 と) 70/900		
制御項目	内容	
3 x 3フィルター	3 x 3フィルターの切り換え	
シャープネス	映像の輪郭の強弱を調整	

◆ これらの項目は、IEEE1394規格のデジタルカメラプロトコルVer.1.31に準拠 しています。詳細はユーザーズガイドをご覧ください。

|主な仕様

関ロ

₩ E

撮像素子 プログレッシブスキャンIT CCD XCD-V60CR/V60/SX90CR/SX90: 1/3型 XCD-U100CR/U100: 1/1.8型

インターフェース仕様

IEEE1394b - 2002

出力信号フォーマット(水平/垂直)

XCD-V60CR/V60: 640 x 480 (VGA) XCD-SX90CR/SX90: 1,280 x 960 (SXGA) XCD-U100CR/U100: 1,600 x 1,200 (UXGA)

フレームレート XCD-V60CR/V60: 90 fps XCD-SX90CR/SX90: 30 fps XCD-U100CR/U100: 15 fps

800/400 Mbps 転送速度 外部トリガー信号(条件)

パルス幅:10 μs以上 極性:負 振幅: DC 5 ~ 24V レンズマウント Cマウント フランジバック 17.526 mm

最低被写体照度 XCD-V60CR/SX90CR/U100CR: 20 lx (F1.4 Gain: +18 dBXCD-V60/SX90/U100: 2 lx (F1.4 Gain: +24 dB)

ガンマ $\gamma = 1$ (LUTで設定可) ゲイン XCD-V60CR/SX90CR/U100CR: $0 \sim +18 \text{ dB} \cdot \text{$\rlap/$}-$ トゲイン

XCD-V60/SX90/U100:0~+24 dB、オートゲイ シャッター速度 1/100,000~16秒、オートシャッター IEEE1394bカメラケーブルまたは12ピンコネク 電源

ター付きカメラケーブルより、DC +8 V ~ +30 V 消費電力 XCD-V60CR/V60/SX90CR/SX90: 2.8 W (DC 12V

入力時) XCD-U100CR/U100: 3.0 W (DC 12V入力時) 性能保証温度 0 ~ +40°C

動作温度 保存温度 -30~+60℃ 使用湿度 20~80% (結露のない状態で) 保存湿度 20~95% (結露のない状態で) 耐振動性 10G (20Hz~200Hz、固定用基準穴使用時) 耐衝擊性 70G

-5~+45°C

外形寸法 44 (W)×33 (H)×57.5 (D)mm、突起部含まず 重量 140g 付属品 レンズマウントキャップ (1)

取扱説明書 (1) 仕様および外観は改良のため予告なく変更することがありますが、ご了承く

ださい。

図G

機器の名称と電気定格は、底面に表示されています。

お使いになる前に、必ず動作確認を行ってください。故障その他に伴う 営業上の機会損失等は保証期間中および保証期間経過後にかかわらず、 補償はいたしかねますのでご了承ください。

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基 づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波 妨害を引き起こすことがあります。この場合には使用者が適切な対策を 講ずるよう要求されることがあります。

定期交換部品について

本機で使用されている部品の中には有寿命部品として定期交換が必要な もの(電解コンデンサーなど)があります。 使用環境や条件により部品の寿命は異なりますので、長期間ご使用され

る場合は定期点検をお勧めします。 ◆ 詳しくはお買い上げ店にお問い合わせください。

English

Fig. D Rear

♠ IEEE1394b connectors

Connect an IEEE1394b camera cable (not supplied) to this connector.

Pin No.	Signal	Pin No.	Signal
1	TPB-	6	VG
2	TPB+	7	NC
3	TPA-	8	VP
4	TPA+	9	TPBG
5	TPAG		

6 12-pin I/O connector

When power from the IEEE1394b connector is insufficient, power is supplied through this connector.

Connect a camera cable such as the CCXC-12P05N to this connector.

Pin No.	Signal	Pin No.	Signal
1	Power GND	7	GPIO IN 2
2	Power IN	8	GPIO OUT 2-
3	ISO GND	9	GPIO OUT 2+
4	Strobe OUT	10	GPIO IN 1
5	GPIO OUT 1-	11	Trigger IN
6	GPIO OUT 1+	12	ISO GND

Installation

Fitting the lens	Fig. E
------------------	--------

1 Remove the lens mount cap. 2 Screw in the lens (not supplied), and turn it until it is secured.

Note

Clean the optical filter with a commercially available blower brush to remove

Using a tripod

To use the tripod, install the VCT-ST70I tripod adaptor (not supplied) on the camera module. Use a tripod screw with a protrusion (ℓ) extending from the installation surface, as follows:

ISO standard: Length 4.5 mm to 5.0 mm ASA standard: Length 0.197 inches Tighten the tripod screws using a hand screwdriver.

When you install the tripod adaptor, use the screws supplied with the tripod

adaptor. Fig. G

Connecting the camera cable

Connect a commercially available IEEE1394b camera cable to the IEEE1394b connector and the 1394b interface connector of your PC. When you connect the cable, insert the cable connector into the IEEE1394b connector until it snaps into place, holding it. Then, tighten the fixing screws placed on both sides of the cable connector.

1 IEEE1394b connector

2 Fixing screws 3 IEEE1394b camera cable (not supplied)

Note

Loose fixing screws may cause a poor connection or damage to the camera or cable. Be sure to tighten the fixing screws.

Power can be supplied to the camera module via the DC-700/700CE camera

When power supply from the IEEE1394b connector is insufficient

adaptor (optional) and a camera cable such as CCXC-12P05N (optional) if power supply from the IEEE1394b connector is insufficient.

12-pin I/O connector 2 Camera cable (e.g. CCXC-12P05N)

3 to AC power source 4 CAMERA connector

5 AC IN connector 6 Trigger generator

Controlling the Camera from Your PC

You can control the camera from your PC. The following table shows the control

Functions common to all models

Control function	Description		
Gain	Color model	0 to +18 dB	
	Black and white model	0 to +24 dB	
Shutter	Setting the shut	ter speed between 1/100,000 and 16 sec.	
Brightness	Pedestal level ad	ljustable	
Gamma	Customizing the (10 bits) (IIDC ext	gamma curve using 1,024 gamma tables tended function)	
Trigger	width) supported	by register) and Mode 1 (control by pulse d for hardware trigger/software trigger aands supported for software trigger	
Strobe Out	Setting the delay width by register	r from the exposure start and the pulse r value	
AutoExposure		ant average image level by the image nd feedback to gain and shutter	
AutoExposure Detection Frame Setting	Setting the detection area for Auto Exposure		
GPIO	Assigning GPIO (General-Purpose Input/Output) to the 12-pin connector		
MemoryShot	Saving an image to the built-in frame memory and reading the saved image from the memory		
ISO Enable (Video Start)	Starts transmitting an image in continuous mode		
OneShot/	OneShot	Transmitting an image	
MultiShot	MultiShot	Transmitting the specified number of images	
DataDepth	Indicating the ef	fective bit length in 16-bit mode	
Cameralnitialize	Resetting the ca	mera to the default features	
MemoryChannel	PresetMemory0 (factory default status) and 1 user available memory channel / 15 user available memory channels selectable		
1394 Bus Synchronization	Defining the exposure timing in synchronization with the cycle time register of 1394 bus		
TriggerDelay	Specifying the d trigger becomes	elay time after which the received effective	
PartialScan	Partition by a un	it of 32 lines x 24 pixels available	
UserFreeMemory	A 256-byte user available memory provided		
Bulk Mode	Acquiring images continuously by changing the settings		

in memory channels

XCD-V60CR/SX90CR/U100CR (color models) only

Control function	Description
WhiteBalance (Raw mode)	Adjusting the R and B levels individually Auto white balance, One Push white balance available
G Gain	Adjusting the G gain
OpticalFilter	Switching the Bayer pattern

XCD-V60/SX90/U100 (black and white models) only

ACD-V60/3A90/O 100 (black and white models) only		
Control function	Description	
3 x 3 Filter	Switching the 3 x 3 filter	
Sharpness	Adjusting the image contour strength	

 $These \ control\ items\ comply\ with\ Digital\ Camera\ Protocol,\ Ver.\ 1.31, of\ the\ IEEE 1394\ Standard.$ For more details, refer to the Technical Manual

Specifications

Transfer speed

Pickup device Progressive scan IT CCD XCD-V60CR/V60/SX90CR/SX90: 1/3 type XCD-U100CR/U100: 1/1.8 type

IEEE1394b - 2002 Interface Output signal format (horizontal/vertical) XCD-V60CR/V60: 640 x 480 (VGA)

XCD-SX90CR/SX90: 1,280 x 960 (SXGA) XCD-U100CR/U100: 1,600 x 1,200 (UXGA)

800/400 Mbps

XCD-V60CR/V60: 90 fps Frame rate XCD-SX90CR/SX90: 30 fps XCD-U100CR/U100: 15 fps

External trigger signal (conditions) Pulse width: 10 µs or more

Polarity: Negative Amplitude: 5 to 24 V DC C-mount

Lens mount Flange back 17.526 mm XCD-V60CR/SX90CR/U100CR; 20 lx (F1.4, Gain; +18 Minimum illumination

XCD-V60/SX90/U100: 2 lx (F1.4, Gain: +24 dB) γ = 1 (selectable by LUT) Gamma XCD-V60CR/SX90CR/U100CR: 0 to +18 dB, Auto Gain

XCD-V60/SX90/U100: 0 to +24 dB, Auto gain 1/100,000~16 seconds, Auto shutter Shutter speed +8 V to +30 V DC from IEEE1394b camera cable or Power camera cable with 12-pin connector

XCD-V60CR/V60/SX90CR/SX90: 2.8 W (12 V DC Power consumption input) XCD-U100CR/U100: 3.0 W (12 V DC input)

Performance guaranty temperature 0 to +40°C (32 to 104°F) -5 to +45°C (23 to 113°F) Operating temperature Storage temperature -30 to +60°C (-22 to 140°F)

Operating relative humidity 20 to 80% (no condensation) Storage relative humidity 20 to 95% (no condensation)

10 G (20 Hz to 200 Hz, at using the reference holes) Vibration resistance Shock resistance External dimension (w/h/d) $44 \times 33 \times 57.5$ mm $(1^3/_4 \times 1^3/_{16} \times 2^3/_8$ inches), not

including projecting parts Mass 140 g (4 oz) Accessories Lens mount cap (1) Operating Instructions (1)

Design and specifications are subject to change without notice.

The nameplate is located on the bottom.

Fig. F

Fig. H

Note Always verify that the unit is operating properly before use. SONY WILL NOT BE LIABLE FOR DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION OR REIMBURSEMENT ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS DUE TO FAILURE OF THIS UNIT, EITHER

DURING THE WARRANTY PERIOD OR AFTER EXPIRATION OF THE WARRANTY,

OR FOR ANY OTHER REASON WHATSOEVER.

Regular parts replacement Some of the parts that make up this product (electrolytic condenser, for example) need replacing regularly depending on their life expectancies. The lives of parts differ according to the environment or condition in which this product is used and the length of time it is used, so we recommend

regular checks. Consult the dealer from whom you bought it for details.

ユーザーズガイドについて

この取扱説明書は本機の基本的な機能と使用方法について記載しており

より詳しい情報をお知りになりたい方は「ユーザーズガイド」をご覧くだ

さい。 「ユーザーズガイド」については営業担当者にお問い合わせください。

お問い合わせ ソニー株式会社 B2Bソリューション事業本部 ビジネス&プロフェッショナルシステム事業部 イメージセンシング部 IS販売推進室 神奈川県厚木市旭町4-14-1 〒 243-0014 Fax. 046-202-6780 Tel. 046-202-8594

http://www.sony.co.jp/ISPJ/ ソニー株式会社 〒108-0075 東京都港区港南1-7-1

About the Technical Manual

The Operating Instructions describe the functions and use of this product. For more details, see the Technical Manual. Please ask your sales

representative about the Technical Manual.

